


STEPS

★ One Tool (Hex Wrench) 

(1) Hardware

Top & Bottom Poles

Left & Right Poles




(2) Printed Graphic Fabric Banner (Optional)





STEP 01

Set up top & bottom poles by connecting according to labelings and telescope properly.




Set up left & right poles by telescoping properly.







STEP 02

Place all connected poles around banner, left & right poles' thick heads towards bottom feet, and insert them into pole pockets.



STEPS

STEP 03 Connect corner poles with thumb knobs.**STEP 04** Assemble feet with hex wrench & screws.

Width is adjustable from 6ft to 10ft
Height is adjustable from 4ft to 8ft